

# Tabela para Atenuador

<i><b>ATENUADOR</b></i>			<i><b>PORTA</b></i>		
<i><b>POTÊNCIA KVA</b></i>	<i><b>A</b></i>	<i><b>L</b></i>	<i><b>C</b></i>	<i><b>A</b></i>	<i><b>L</b></i>
<b>12-20</b>	600	800	1000	2100	900
<b>55-75-81</b>	900	800	1000	2100	900
<b>110-140-150</b>	900	1200	1000	2100	900
<b>180-200-230</b>	1200	1000	1000	2100	1100
<b>255-290</b>	1200	1200	1200	2100	1100
<b>330-360</b>	1200	1400	1200	2100	1100
<b>450</b>	1500	1400	1200	2100	1600
<b>500-563-631</b>	1500	1800	1200	2100	1600
<b>750</b>	1800	2000	1200	2500	1800
<b>1100</b>	2400	2000	1200	2500	2000

